





Codice / Code	Descrizione / Description	H(mm)	L (mm)	W (mm)	Pezzi/Pack
70 031122	Montante destro / Right lock	400	89	29	1
70 031123	Montante sinistro / Left lock	400	89	29	1
70 031126	Montante destro / Right lock	600	89	29	1
70 031127	Montante sinistro / Left lock	600	89	29	1
70 031154	Montante destro leva bassa / Right lock short lever	800	89	29	1
70 031155	Montante sinistro leva bassa / Left lock short lever	800	89	29	1
70 031156	Montante destro leva alta / Right lock high lever	800	89	29	1
70 031157	Montante sinistro leva alta / Left lock high lever	800	89	29	1

Codice / Code	Descrizione / Description	H(mm)	L (mm)	W (mm)	Pezzi/Pack
70 031148	Montante destro / Right lock	400	76	29	1
70 031149	Montante sinistro / Left lock	400	76	29	1
70 031152	Montante destro / Right lock	600	76	29	1
70 031153	Montante sinistro / Left lock	600	76	29	1
70 031160	Montante destro leva bassa / Right lock short lever	800	76	29	1
70 031161	Montante sinistro leva bassa / Left lock short lever	800	76	29	1
70 031150	Montante destro leva alta / Right lock high lever	800	76	29	1
70 031151	Montante sinistro leva alta / Left lock high lever	800	76	29	1
70 031158	Montante destro leva bassa c/2 naselli / Right lock	1000	76	29	1
70 031159	Montante sinistro leva bassa c/2 naselli / Left lock	1000	76	29	1